
Meridian 1

Software Input/Output Guide

X11 System Messages

Document Number: 553-3001-411
Document Release: Standard 4.00
Date: October 1997

© 1995, 1997
All rights reserved

Printed in Canada

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

October 1997

Standard 4.00. This document is issued to include updates and changes required for X11 Release 23.0x

August 1996

Standard 3.00. This document is issued to include updates and changes required for X11 Release 22.0x.

December 1995

Standard 2.00. This document is up-issued to include updates and changes required for X11 Release 21.1x.

July 1995

Standard 1.00. This document is issued to include updates and changes required for X11 Release 21.0x.

This document has the new NTP number 553-3001-411 and contains error message modules previously contained in International NTPs 553-2311-311 and 553-2301-511 and Book 2 of North American NTP 553-3001-400.

Tell us what you think...

This is your document. Nortel wants it to work well for you.

Please take a few minutes to answer the questions on the other side of this page. Fax it back to us at the number provided, or mail it to the address below.

Your comments will be used to make improvements.

Thank you. We appreciate your time and consideration.

Nortel Product Training and Documentation

Return mail address:

Documentation User Comments Survey
Nortel Product Training & Documentation
P.O. Box 833858
m/s H300
Richardson, Texas 75083-3858
USA

Fax to:

Documentation User Comments Survey
Nortel Product Training and Documentation
1-972-684-8699

Document name _____

Document NTP or P0 number (if available) _____

Please circle the most appropriate number on the scale for each question.

1. Overall, are you satisfied with this document?
Yes 7 6 5 4 3 2 1 No
2. Is it easy to find information in this document?
Yes 7 6 5 4 3 2 1 No
3. Have you found the information in this document to be technically accurate?
Yes 7 6 5 4 3 2 1 No
4. Is this document clearly written?
Yes 7 6 5 4 3 2 1 No
5. Is the information in this document complete for its purpose?
Yes 7 6 5 4 3 2 1 No
6. Does this document help you do your job?
Yes 7 6 5 4 3 2 1 No

Comments:

Optional: Your name _____ Fax _____
Company _____

Contents - Book 1 of 2

General	1
ACD: Automatic Call Distribution Load Management	3
ADD: Automatic Call Distribution Data Dump ...	11
AMH: Auxiliary Message Handler	13
AML: Application Module Link (LD 48)	15
AML: Application Module Link Maintenance (LD 48)	17
ATM: Automatic Trunk Maintenance (LD 92)	21
AUD: Software Audit (LD 44)	25
AUTH: Authorization Code (LD 88)	51
BERR: Bus Error Monitor	53
BIC: Bus Interface Circuit	57
BKP: Remote Backup (Option 11)	59
BRI: Basic Rate Interface	63
BSD: Background Signaling Diagnostic (LD 45) .	81

BUG: Software Error Monitor	105
CCBR: Customer Configuration Backup and Restore	261
CCED: Core Common Equipment Diagnostic (LD 135)	263
CCR: Customer Controlled Routing	271
CDM: Call Detail Recording Diagnostic (LD 40, LD 42)	273
CED: Common Equipment Diagnostic (LD 35) ..	287
CIOD: Core Input/Output Diagnostic (LD 137) ...	297
CMF: Compelled Multifrequency Diagnostic (LD 54)	309
CMON: Core Monitor	311
CND: Caller's Name Display	313
CNF: Conference Circuit Diagnostic (LD 38)	315
CNI: Core to Network Interface	319
CNV: Conversion (LD 66)	323
COM: Data Communication	325
CRI: Carrier Remote IPE	327
CSA: Command and Status Link Diagnostic (LD 48)	331
CSC: Customer Service Change	337

DBMT: Database Media Transfer	341
DCH: D-channel Diagnostic (LD 96)	345
DLO: Disk Layout	359
DSET: Digital Set Download	361
DTA: Digital Trunk Diagnostic	363
DTC: Digital Trunk Clock Controller Diagnostic (LD 60)	375
DTD: Dial Tone Detector Diagnostic (LD 34)	379
DTI: Digital Trunk Interface Diagnostic (LD 60) ..	381
DTM: Digital Trunk Maintenance (LD 75)	391
DTRK: Digital Trunk Diagnostic (LD 60)	399
EDD: Equipment Data Dump (LD 43)	401
EHM: Automatic Patch Retention	407
EMR: Emergency Key (ACD)	411
ERR: Error Monitor (Hardware)	413
ESDA: Enhanced Serial Data Interface (LD 48) ..	469
ESDI: Enhanced Serial Data Interface (LD 48) ...	471
ESN: Electronic Switched Network (LD 86, LD 87 and LD 90)	473
FHW: Faulty Hardware	483
FIR: Fibre Remote IPE	489

HEX: Hexadecimal Codes and Conversion 493

HWI: Hardware Infrastructure Maintenance 529

HWR: Hardware Reset 535

Contents - Book 2 of 2

ICU: Intercept Computer Update (LD 51)	539
IGS: Intergroup Switch and System Clock Generator	541
INI: Initialize	543
IOD: Input/Output Diagnostic (LD 37)	555
ISR: Intergroup Switch and System Clock Generator Diagnostic (LD 39)	569
LNK: Link Diagnostic (LD 48)	573
MAT: Meridian Administration Tools	583
MCT: Malicious Call Trace	585
MEM: Memory Management (LD 29)	587
MFC: Multifrequency Compelled Signaling (LD 54)	589
MFD: Multifrequency Signaling Diagnostic (LD 54)	591
MFE: Multifrequency Signaling Diagnostic (LD 54)	597
MFK: Multifrequency Signaling for KD3	599
MFR: Multifrequency Receiver	601
MFS: Multifrequency Sender Diagnostic for ANI (LD 46)	603
MISP: Multi-purpose ISDN Signaling Processor .	605
MOB: Mobility	611

MPH: Meridian Packet Handler	619
MRB: Message Registration Block	623
MSDL: Multi-purpose Serial Data Link	625
MSR: Multigroup Switch Replacement (LD 39) ..	633
MWL: Message Waiting Lamps Reset (LD 61) ...	637
NACD: Network Automatic Call Distribution	639
NCT: Network Call Trace	641
NPR: Network and Peripheral Equipment Diagnostic (LD 32)	667
NWS: Network and Signaling Diagnostic (LD 30)	677
OHAS: Off-Hook Alarm Security	689
OSM: Operating System Messaging	691
OSN: On-Site Notification	693
OVD: Overload Monitor	695
OVL: Overlay Loader	699
PCH: System Patch reports	707
PMS: Property Management System Interface ..	713
PRI: Primary Rate Interface Diagnostic (LD 60)	715
PWR: Power and System Monitor	733

RCV: Recovery Messages	737
RPD: 1.5 Mb/s Remote Peripheral Equipment Diagnostic (LD 33)	739
RPE: 2.0 Mb/s Remote Peripheral Equipment Alarm Handler Diagnostic (LD 53)	745
RPL: 1.5 Mb/s Remote Peripheral Equipment Local End Diagnostic (LD 62)	751
RPM: 2.0 Mb/s Remote Peripheral Equipment Diagnostic (LD 53)	755
RPT: System Reporting	761
SCH: Service Change	763
SCSI: Small Computer System Interface	965
SDL: Peripheral Software Download	969
SECA: Security Administration Alarm	975
SRPT: System Reports	977
SYS: System Loader	985
TDS: Tone and Digit Switch Diagnostic (LD 34)	1051
TEMU: Tape Emulation	1059
TFC: Traffic Control (LD 2)	1065
TFN: Customer Network Traffic	1069
TFS: Traffic Measurement	1071

TMF: Test Multifrequencies 1073

TRA: Call Trace (LD 80) 1075

TRK: Trunk Diagnostic (LD 36, LD 41) 1079

TSM: Time Slot Monitor 1093

TTY: Teletype Error Reports 1095

VAS: Value Added Server 1097

**XCT: Conference, Tone and Digit Switch, and
Multifrequency Sender Cards 1105**

XMI: Network to Controller Message Interface . 1107